

SENTINEL® WALKWAY PAD

Protects roof membranes from damage

DESCRIPTION

SENTINEL® Walkway Pad protects roof membranes from damage caused by necessary foot traffic or accidental tool drops. This product is compatible with SENTINEL® PVC roof membranes and can be applied to new or existing roofs using standard hot air welding equipment.

TECHNICAL CHARACTERISTICS

PROPERTY	VALUE	TEST METHOD
Thickness , in	0.156	ASTM D412
Tear resistance , lbf/in	200	ASTM D624
Elongation , %	100	ASTM D412
Dimensional stability , %	0.25 (max change)	ASTM D1204
Accelerated weathering	Pass @ 5,000 hours	ASTM G155

* All values shown are nominal and subject to normal manufacturing tolerances.



PRODUCT INFORMATION*

PRODUCT #	COLOR	WIDTH	LENGTH	ROLL WEIGHT
P900	Light Gray	30	50	80

* All values shown are nominal and subject to normal manufacturing tolerances.

APPLICATION

Remove any loose debris and clean PVC roof membrane, then allow to dry prior to application of walkway. Roll out and cut desired length up to 10 feet and allow to relax while placing into the desired position. Install SENTINEL® Walkway Pad with a continuous weld around the perimeter. Refer to Performance Roof Systems specifications and installation instructions for additional application guidelines.

STORAGE & HANDLING

Store rolls on end and maintain in an upright position to prevent damage. Store rolls in a clean, dry location and cover as necessary to protect rolls from environmental damage such as extreme cold, heat or moisture. Monitor varying environmental conditions during storage, handling and application.